

VEEDER-ROOT



SLIM HUBODOMETER

INSTALLATION INSTRUCTIONS

MANUAL NO. 350343

March 2018

A. MOUNTING. Slim Hubodometers are manufactured to be mounted on an axle hub that is inset. A Veeder-Root mounting bracket is available for installations on vehicles or equipment that have different hub configurations. Concentricity of the hubodometer to axle must be within .062 in. (1.6 mm).

B. INSTALLATION. Install the hubodometer as follows:

1. Insert the hubodometer mounting stud into the mounting hole.
2. Install the washer over the stud and secure with the lock nut.
3. Torque the nut to 13.3-16.2 lb-ft (12-15 N-m) maximum.
4. If installation is on a Veeder-Root bracket, install bracket per instructions shipped with it.
5. Consult Veeder-Root on any unusual application, installation, or possible modification of this basic design.

C. CLEANING. Use a mild detergent and water to clean hubodometer crystal.

PN: 0230279-

Rev. B Mar 2018