

# CattronControl™ LRC-S1 Operator Control Unit (OCU)

Remote Control System  
User Manual

9M02-9124-A001-EN



## Revision History

| VERSION | DATE    | NOTES                                                                    |
|---------|---------|--------------------------------------------------------------------------|
| 1.0     | 08/2013 | Initial release                                                          |
| 1.1     | 06/2014 | Updated battery pack images and information                              |
| 1.2     | 01/2015 | Updated support<br>Added cleaning warning<br>Added membrane labels image |
| 1.3     | 04/2016 | Updated support facilities<br>Updated confidentiality notice             |
| 1.4     | 04/2016 | Updated support facilities<br>Updated confidentiality notice             |
| 2.0     | 05/2020 | Document rebranded and contact information updated                       |

*Any information furnished by Cattron™ and its agents is believed to be accurate and reliable. All specifications are subject to change without notice. Responsibility for the use and application of Cattron products rests with the end user since Cattron and its agents cannot be aware of all potential uses. Cattron makes no warranties as to non-infringement nor as to the fitness, merchantability, or sustainability of any Cattron products for any specific or general uses. Cattron Holdings, Inc., or any of its affiliates or agents shall not be liable for incidental or consequential damages of any kind. All Cattron products are sold pursuant to the Terms and Conditions of Sale, a copy of which will be furnished upon request. When used as a tradename herein, Cattron means Cattron Holdings, Inc. or one or more subsidiaries of Cattron Holdings, Inc. Cattron™, corresponding logos, and other marks are trademarks or registered trademarks of Cattron Holdings, Inc. Other marks may be the property of third parties. Nothing herein provides a license under any Cattron or any third party intellectual property right.*



## Contents

|       |                                                                                |    |
|-------|--------------------------------------------------------------------------------|----|
| 1     | Important Notes.....                                                           | 4  |
| 2     | Safety Instructions.....                                                       | 5  |
| 2.1   | Warnings and Cautions.....                                                     | 5  |
| 3     | System Description.....                                                        | 7  |
| 3.1   | The Hand-Held Operator Control Unit (OCU).....                                 | 7  |
| 4     | Operation.....                                                                 | 11 |
| 4.1   | Prepare the Battery.....                                                       | 11 |
| 4.2   | Selecting the TransKeys.....                                                   | 11 |
| 4.3   | Turning on the OCU.....                                                        | 11 |
| 4.3.1 | Prestart Check.....                                                            | 11 |
| 4.3.2 | Default Start Sequence.....                                                    | 12 |
| 4.3.3 | Alternate Start Sequence.....                                                  | 12 |
| 4.3.4 | Optional STOP Switch Test Sequence.....                                        | 12 |
| 4.3.5 | Normal Operation.....                                                          | 13 |
| 4.4   | Changing the Battery.....                                                      | 13 |
| 4.5   | Charging the Battery.....                                                      | 14 |
| 4.5.1 | Preparing the Battery Charging Unit.....                                       | 14 |
| 4.5.2 | Charging the Battery Pack.....                                                 | 16 |
| 4.5.3 | Charging Status Indication via LEDs.....                                       | 17 |
| 4.5.4 | Battery Maintenance.....                                                       | 17 |
| 5     | System Fault/Status Messages.....                                              | 18 |
| 5.1   | OCU Fault/Status Messages.....                                                 | 18 |
| 6     | Maintenance Instructions.....                                                  | 19 |
| 6.1   | Preventive Maintenance.....                                                    | 19 |
| 7     | Technical Data.....                                                            | 20 |
| 7.1   | Transmitter (OCU).....                                                         | 20 |
| 7.2   | Battery Charger.....                                                           | 20 |
| 8     | Technical Support.....                                                         | 21 |
|       | Appendix – RF Channels.....                                                    | 22 |
|       | 433-434 MHz Frequency Band (Europe).....                                       | 22 |
|       | 902-927 MHz Frequency Band (North America and other applicable countries)..... | 24 |



## 1 Important Notes

### ***Information to the User regarding Radio and Functional Safety Compliance:***

- Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment
- Changes or modifications may invalidate Radio Certification and Functional Safety
- In the case of equipment that is supplied as compliant with FCC Part 15 and Industry Canada ICES-003 standards, the following notice applies:

---

**Note:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation

---

- This manual is Confidential and Proprietary to Cattron – the entire document including any or all of the information contained therein is not to be reproduced, disclosed, or used in whole or in part for any purpose without prior written authorization of Cattron



## 2 Safety Instructions

### 2.1 Warnings and Cautions

WARNING statements are strategically placed throughout this document prior to all operating and maintenance procedures, practices or conditions considered essential to the protection of personnel or equipment and property. A WARNING applies each time the related step is repeated. Before starting any task, review and understand the WARNINGS included in the text. All WARNINGS appearing in this manual are included below.

|                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p><b>WARNING</b></p> <p>MORE THAN ONE REMOTE CONTROL SYSTEM MAY BE USED AT, AROUND OR NEARBY YOUR OPERATING FACILITY. THEREFORE, BEFORE INSERTING A TRANSKEY INTO AN OCU, BE SURE THE CORRECT CODED TRANSKEY IS SELECTED FOR THE DESIRED EQUIPMENT TO OPERATE.</p> <p>IF THE WRONG TRANSKEY IS INSERTED INTO AN OCU, OTHER REMOTE CONTROLLED EQUIPMENT LOCATED AT, AROUND OR NEARBY YOUR FACILITY MAY BECOME OPERATIONAL.</p> <p>FAILURE TO COMPLY WITH THE ABOVE WARNINGS MAY RESULT IN UNINTENDED OPERATION OF REMOTE CONTROLLED EQUIPMENT, WHICH COULD RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT.</p> |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p><b>WARNING</b></p> <p>BEFORE ATTEMPTING TO USE THE REMOTE CONTROL SYSTEM, VERIFY THE TARGET CRANE OR MACHINE YOU WISH TO OPERATE IS UNDER THE DIRECT COMMAND OF YOUR OCU. THIS IS ACCOMPLISHED BY OPERATING A NON-MOTION OCU FUNCTION SUCH AS A HORN OR LAMP AND OBSERVING THAT THE RESPECTIVE FUNCTION ON THE TARGETED CRANE OR MACHINE RESPONDS.</p> <p>FAILURE TO COMPLY WITH THE ABOVE WARNING MAY RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT.</p> |
|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p><b>WARNING</b></p> <p>DO NOT OPEN THE BATTERY CHARGING UNIT.</p> <p>TO PREVENT A FIRE HAZARD OR AN ELECTRIC SHOCK, PROTECT THE UNIT AGAINST MOISTURE AND RAIN.</p> <p>OPERATE THE BATTERY CHARGING UNIT IN DRY, INDOOR SPACES ONLY. DO NOT USE THE BATTERY CHARGING UNIT IF THE HOUSING OR MAIN POWER PLUG IS DAMAGED.</p> <p>FAILURE TO COMPLY WITH THE ABOVE WARNINGS MAY RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT.</p> |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                     |                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p><b>WARNING</b></p> <p>LRC-S BATTERY CHARGING UNITS ARE DESIGNED ONLY FOR USE WITH CATTRON NICKEL METAL HYDRIDE (NI-MH) BATTERY PACKS. OTHER BATTERY PACKS MAY EXPLODE WHEN CHARGED WITH THIS DEVICE.</p> <p>FAILURE TO COMPLY WITH THE ABOVE WARNING MAY RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT.</p> |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|



|                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|                                                                                     | <p>USING UNAPPROVED COMPONENTS OR ACCESSORIES IN THE SYSTEMS SOLD BY CATTRON IS STRICTLY PROHIBITED. UNAPPROVED COMPONENTS ARE DEFINED AS ANY COMPONENT NOT INSPECTED AND SOLD BY CATTRON. THIS ALSO INCLUDES ANY COMPONENT MODIFIED FROM ITS INTENDED USE AND/OR ANY COMPONENT EXHIBITING OBSERVABLE DAMAGE OR DEFECT.</p> <p>USE OF NON-CONFORMING PARTS, ASSEMBLIES AND ACCESSORIES MAY LEAD TO INJURY OR DEATH AND DAMAGE TO EQUIPMENT.</p>                                                                                                                                                                                                                                                                                                                                                 |
|    | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|                                                                                     | <p>THE REMOTE CONTROL SYSTEM YOU HAVE PURCHASED IS DESIGNED TO STOP IN A SAFE MODE UNDER A VARIETY OF CONDITIONS. SOME EXAMPLES OF THESE CONDITIONS ARE EXCESSIVE RADIO SIGNAL INTERFERENCE, LOSS OF BATTERY AND/OR ELECTRIC POWER, FAILURE OF CERTAIN COMPONENTS, OPERATION BEYOND SIGNAL RANGE AND OTHERS. ALTHOUGH CATTRON DOES NOT SPECIFY THE POSITION OF THE OPERATOR WHEN CONTROLLING THE EQUIPMENT, WE ARE AWARE THAT SOME USERS ARE INSTRUCTED AND TRAINED BY THEIR EMPLOYER TO RIDE THE EQUIPMENT IN A SAFE MANNER. IT IS IMPERATIVE THAT YOU ARE PREPARED FOR AN UNPLANNED STOP OF THE EQUIPMENT AT ANY TIME. DO NOT PLACE YOURSELF OR OTHERS IN A POSITION WHERE THIS SITUATION MAY CAUSE A FALL FROM THE EQUIPMENT.</p> <p>FAILURE TO USE CAUTION MAY LEAD TO INJURY OR DEATH.</p> |
|   | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|                                                                                     | <p>ONLY CLEAN THE OCU EXTERIOR RESIN USING METHYL OR ISOPROPYL ALCOHOL, MILD SOAP SOLUTIONS, HEPTANE OR HEXANE. DO NOT CLEAN WITH PARTIALLY HYDROGENATED HYDROCARBONS, KETONES (SUCH AS MEK), STRONG ACIDS OR WITH ALKALINES (SUCH AS SODIUM HYDROXIDE).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|  | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|                                                                                     | <p>DO NOT IMMERSE THE OCU IN WATER.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |



## 3 System Description

The LRC-S Operator Control Unit (OCU) is part of a remote control system that can be made to serve a wide range of applications, from standard electric overhead traveling (EOT) cranes through highly customized cranes and machines.

The LRC-S OCU and its chosen, matching Machine Control Unit (MCU) can be factory manufactured to match the exact requirements of an individual customer.

LRC-S remote control systems offer the safety and dependability required for industrial control applications with reversing motor control such as overhead cranes, conveyors, etc. The remote control system described in this manual incorporates high-performance, safety-critical design for maximum safety. Each system includes one or more **OCUs** and one or more **MCUs**.

### 3.1 The Hand-Held Operator Control Unit (OCU)

The LRC-S OCU is a lightweight, ergonomic, hand-held OCU designed to withstand tough industrial environments which may include humidity, oil, vibrations, shock and wide temperature fluctuations.

Each OCU is configured and manufactured to satisfy a specific control application. Referring to [Figure 1](#), an LRC-S1 OCU incorporates the following controls and indicators:

- Two joysticks
- One 'STOP' switch
- Five definable pushbutton switches
- One multicolor 'STATUS' LED
- Six function LEDs
- One predefined 'HORN' pushbutton switch
- One predefined Power 'ON/OFF' pushbutton switch
- One internal acoustic buzzer
- One optional LCD screen

Each OCU comes with a sheet of adhesive labels (Part Number 3LBL-9121-B102), shown in [Figure 2](#), that can be used to identify the product's switches and features. Remove each applicable label and adhere it to the appropriate area of the OCU membrane as illustrated in [Figure 3](#).






Figure 1: LRC-S Joystick OCU





Figure 2: LRC S1 OCU Label Sheet








**Figure 3: LRC-S OCU Sample Membrane (Label Locations Circled in Red)**

Operational security advances to its maximum through the use of a removable TransKey which, when installed to the OCU, defines and enables the specific operating parameters, as illustrated in [Figure 4](#).



**Figure 4: Removable TransKey and Battery Pack**



---

**Note:** Do not swap the OCU and MCU TransKeys. The OCU (transmitter) TransKey is black. The MCU (receiver) TransKey is yellow. Swapping TransKeys results in OCU/MCU fault indications and the system will not operate.


---

LRC-S OCUs are equipped with an internal antenna with a typical operating range in excess of 120 m (400 ft) uninterrupted line-of-sight. Understand that the operating range varies with environmental conditions and the selected radio module. Should the OCU go out of operating range, all motions on the crane or controlled machine will stop.

All LRC-S OCUs are powered by rechargeable 4.8 V, 1600 mAh, Nickel Metal Hydride (Ni-MH) battery packs.

A worldwide, all-purpose, plug-in battery pack charger, complete with battery adapter, is provided with the unit. This allows Ni-MH battery packs to charge from a power source between 100 to 240 VAC at 50-60 Hz.

LRC-S OCUs are normally hand carried by the operator. Referring to [Figure 5](#), an optional body carrying strap (Part Number MT 006-00295) is available on request.



**Figure 5: Optional Body Carrying Strap**



## 4 Operation

### 4.1 Prepare the Battery

Fully charge the OCU rechargeable battery pack before using the remote control system for the first time.

**Note:** Charging the battery pack can take up to three hours.

Refer to [Section 4.4](#) and [Section 4.5](#) for battery changing and charging instructions, respectively.

### 4.2 Selecting the TransKeys

Due to the flexible TransKey concept, it is common for one OCU to control multiple cranes or machines. Each crane or machine is provided with a unique pair of TransKeys with the same address. Insert this pair of TransKeys into their respective OCU and MCU locations before carrying out remote control operations.

|                                                                                   |                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>WARNING</b>                                                                                                                                                                                                                         |
|                                                                                   | MORE THAN ONE REMOTE CONTROL SYSTEM MAY BE USED AT, AROUND OR NEARBY YOUR OPERATING FACILITY. THEREFORE, BEFORE INSERTING A TRANSKEY INTO AN OCU, BE SURE THE CORRECT CODED TRANSKEY IS SELECTED FOR THE DESIRED EQUIPMENT TO OPERATE. |
|                                                                                   | IF THE WRONG TRANSKEY IS INSERTED INTO AN OCU, OTHER REMOTE CONTROLLED EQUIPMENT LOCATED AT, AROUND OR NEARBY YOUR FACILITY MAY BECOME OPERATIONAL.                                                                                    |
|                                                                                   | FAILURE TO COMPLY WITH THE ABOVE WARNINGS MAY RESULT IN UNINTENDED OPERATION OF REMOTE CONTROLLED EQUIPMENT, WHICH COULD RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT.                                       |

### 4.3 Turning on the OCU

The OCU start sequence is configurable and is supplied preset to either ‘Default’ or ‘Alternate’; both sequences can include a STOP Switch Test Routine.

#### 4.3.1 Prestart Check

Be sure to insert the correct TransKey – refer to [Figure 4](#) for the OCU TransKey location.

**Note:** Do not swap the OCU and MCU TransKeys. The OCU (transmitter) TransKey is black. The MCU (receiver) TransKey is yellow. Swapping TransKeys results in OCU/MCU fault indications and the system will not operate.

Make sure the STOP switch is in the “out” position. If the switch has been pushed down to the ‘STOP’ position, you first must unlatch the switch knob by rotating in a clockwise direction.



|                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|                                                                                   | <p>BEFORE ATTEMPTING TO USE THE REMOTE CONTROL SYSTEM, VERIFY THE TARGET CRANE OR MACHINE YOU WISH TO OPERATE IS UNDER THE DIRECT COMMAND OF YOUR OCU. THIS IS ACCOMPLISHED BY OPERATING A NON-MOTION OCU FUNCTION SUCH AS A HORN OR LAMP AND OBSERVING THAT THE RESPECTIVE FUNCTION ON THE TARGETED CRANE OR MACHINE RESPONDS.</p> <p>FAILURE TO COMPLY WITH THE ABOVE WARNING MAY RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT.</p> |

### 4.3.2 Default Start Sequence

1. Press the ON/OFF button for a minimum of 500 ms, until the STATUS LED turns a steady red. Then release the ON/OFF button.
2. Within 5 seconds following the release of the ON/OFF button, simultaneously press the ON/OFF and Horn buttons, and then release both buttons. “Active” displays on the optional LCD screen and the STATUS LED indicator start flashing green, indicating an RF signal transmission.

---

**Note:** The above operations must be performed within a ten second timeframe.

If the first step is unsuccessful, the unit returns to and maintains power-down mode.

---

### 4.3.3 Alternate Start Sequence

1. Press the ON/OFF button for a minimum of 500 ms, and then release it. The STATUS LED flashes green. The LRC-S is now powered on.

---

**Note:** If this step is unsuccessful, the unit returns to and maintains power-down mode.

---

### 4.3.4 Optional STOP Switch Test Sequence

Testing the STOP Switch may have been predefined and, if required, is performed immediately after the chosen start sequence above.

You may also perform a system STOP at any time during operation by pushing down on the red STOP switch.

If the STOP Switch Test is required,

1. Carry out the required start sequence above; the STATUS LED turns a steady red after initialization and while it waits for the STOP Switch to be depressed.
2. Press the STOP Switch; the STATUS LED turns to steady amber.
3. Release the STOP switch; the STATUS LED becomes a flashing green and the OCU is ready to use.

---

**Note:** The above operations must be performed within a ten second timeframe.

If this step is unsuccessful, the unit returns to and maintains power-down mode.

---



### 4.3.5 Normal Operation

---

**Note:** Operate the remote control transmitter as required. Motion control switches are designed to revert to neutral when released. Any or all functions may be operated simultaneously if the controlled machine permits such operation.

---

In normal operation, the STATUS LED (centrally located above the optional LCD screen) flashes green. When the battery voltage becomes low, the STATUS LED flashes red and a beep sounds every ten seconds to alert the operator that the battery pack needs to be replaced or recharged.

Only Cattron battery packs should be used; if the battery type is not recognized, the STATUS LED flashes yellow. The STATUS LED also illuminates in a series of red blinking sequences to indicate a specific OCU fault, as described in [Section 5.1](#).

The OCU switches off automatically when the following events occur:

- Battery low voltage detected (after a preset time delay)
- Internal fault detected
- STOP switch depressed
- ON/OFF switch pressed

## 4.4 Changing the Battery

Referring to [Figure 6](#), remove the battery pack as follows:

1. Lay the OCU on its side.
2. Remove the rechargeable battery pack from the bottom of the OCU by pressing the battery latch button and sliding out the battery.






Figure 6: Removing the Battery Pack

## 4.5 Charging the Battery

|                                                                                     |                                                                                                                                                                                                                                                                                                        |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>WARNING</b>                                                                                                                                                                                                                                                                                         |
|                                                                                     | LRC-S BATTERY CHARGING UNITS ARE DESIGNED ONLY FOR USE WITH CATTRON NICKEL METAL HYDRIDE (NI-MH) BATTERY PACKS. OTHER BATTERY PACKS MAY EXPLODE WHEN CHARGED WITH THIS DEVICE.<br>FAILURE TO COMPLY WITH THE ABOVE WARNING MAY RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT. |


### 4.5.1 Preparing the Battery Charging Unit

|                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                    |
|                                                                                     | DO NOT OPEN THE BATTERY CHARGING UNIT.<br>TO PREVENT A FIRE HAZARD OR AN ELECTRIC SHOCK, PROTECT THE UNIT AGAINST MOISTURE AND RAIN.<br>OPERATE THE BATTERY CHARGING UNIT IN DRY, INDOOR SPACES ONLY. DO NOT USE THE BATTERY CHARGING UNIT IF THE HOUSING OR MAIN POWER PLUG IS DAMAGED.<br>FAILURE TO COMPLY WITH THE ABOVE WARNINGS MAY RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT. |



Referring to [Figure 7](#), connect the Battery Charging Unit as follows:

1. Select the correct plug for your country of operation.
2. If necessary, shift the locking tab on the back of the charger in the indicated direction and remove the existing plug.
3. Insert the correct plug into the charger until it locks in place with an audible 'click'.
4. Plug the Battery Charging Unit into the main power supply socket.
5. As soon as the charger is connected to the main power supply, the red 'Power' LED (1) illuminates to indicate the ready condition.



**Figure 7: Battery Charging Unit with Interchangeable Plugs**



## 4.5.2 Charging the Battery Pack

Referring to [Figure 7](#), charge the battery pack as follows:

1. Connect the jack plug from the Battery Charging Unit into the battery as shown in [Figure 8](#).



**Figure 8: LRC-S Rechargeable Battery and Charging Port**

|                                                                                     |                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p><b>WARNING</b></p> <p>LRC-S BATTERY CHARGING UNITS ARE DESIGNED ONLY FOR USE WITH CATTRON NICKEL METAL HYDRIDE (NI-MH) BATTERY PACKS. OTHER BATTERY PACKS MAY EXPLODE WHEN CHARGED WITH THIS DEVICE.</p> <p>FAILURE TO COMPLY WITH THE ABOVE WARNING MAY RESULT IN SERIOUS INJURY OR DEATH TO PERSONNEL AND DAMAGE TO EQUIPMENT.</p> |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

2. Plug in the battery pack and observe that the red 'Charge' LED (2, [Figure 7](#)) illuminates to indicate the charging mode. After approximately 5 seconds, a one minute battery test mode starts and is indicated by the blinking green 'Ready' LED (3, [Figure 7](#)). If the green 'Ready' LED illuminates immediately after connecting the battery and the red 'Charge' LED blinks from time to time after 20 seconds, the battery pack is defective and can no longer be charged. If necessary, replace the battery pack with a new one.

**Note:** Charging the battery pack can take up to three hours.

3. When the battery pack is fully charged, the red 'Charge' LED extinguishes and the green 'Ready' LED illuminates.
4. The device switches to pulse trickle charge automatically and after about two minutes the green 'Ready' LED starts blinking. The battery may be used immediately or left until required.





### 4.5.3 Charging Status Indication via LEDs

| Indication                                                    | Description                                                                                                                                                                                                                                      |
|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Red 'Power' LED<br>(item 1, <a href="#">Figure 7</a> )        | Steady illumination indicates the charger is ready for operation. LED illuminates immediately after the charger is connected to the power supply.                                                                                                |
| Red 'Charge' LED<br>(item 2, <a href="#">Figure 7</a> )       | Steady illumination indicates the battery pack is being charged.                                                                                                                                                                                 |
| Green 'Ready' LED<br>(item 3, <a href="#">Figure 7</a> )      | Steady illumination indicates that the battery is charged. The green LED switches to blinking mode after approximately two minutes to indicate pulse trickle charging. During testing mode, the LED blinks in conjunction with the 'Charge' LED. |
| Yellow 'Discharge' LED<br>(item 4, <a href="#">Figure 7</a> ) | After pressing the discharge button for approximately 2 seconds, steady illumination indicates the battery pack is being discharged. Simultaneously, the 'Ready' LED blinks for approximately one minute to indicate the testing phase.          |
| Discharge button<br>(item 5, <a href="#">Figure 7</a> )       | Pressing the discharge button for approximately 2 seconds starts the process to discharge the battery pack.                                                                                                                                      |

### 4.5.4 Battery Maintenance

We recommend discharging the battery packs completely from time to time to preserve their capacity.

Pressing the discharge button (5, [Figure 7](#)) discharges the battery. After completely discharging the battery, which in some cases can take several hours, the charger automatically switches to the charge mode. Once the battery is fully charged, the battery charger switches over to pulse trickle charging.

The battery pack is tested for defects before the charging process begins. During the charging cycle, the battery pack status is continuously monitored to prevent overcharging.



## 5 System Fault/Status Messages

**Note:** Only qualified personnel should make repairs or replacements.

### 5.1 OCU Fault/Status Messages

The OCU has a STATUS LED indicator that displays the current system status to the operator. When an OCU fault is detected, the STATUS LED illuminates red and signals the fault with a series of blinks. Refer to the following table for the blink sequence and the corresponding fault messages.

| OCU STATUS LED Indication | Fault                                                   | Action Required                                                                                                                                                                        |
|---------------------------|---------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2 flashes                 | TransKey missing                                        | Plug in the TransKey                                                                                                                                                                   |
| 3 flashes                 | TransKey cannot be read                                 | Check the TransKey configuration*                                                                                                                                                      |
| 4 flashes                 | Fault in the low-voltage test during switch-on          | Switch the OCU 'OFF' then 'ON' again<br>Replace/charge the battery pack<br>If the fault persists, investigate the fault*<br>Change the transmitter board*<br>Return the OCU for repair |
| 5 flashes                 | Switch-on sequence not performed correctly              | Ensure the STOP pushbutton is released<br>Switch the OCU 'OFF' then 'ON' again                                                                                                         |
| 6 flashes                 | Fault during reading of command initiator               | Investigate the fault*<br>Change the transmitter board/keyboard*<br>Return the OCU for repair                                                                                          |
| 7 flashes                 | Incorrect RF module or RF module incorrectly configured | Replace the RF module or correct the configuration*<br>Return the OCU for repair                                                                                                       |
| 8 flashes                 | General system fault                                    | Investigate the fault*<br>Change the transmitter board*<br>Return the OCU for repair                                                                                                   |
| 9 flashes                 | Low Power Supply voltage                                | Replace/charge the battery pack<br>Change the transmitter board*<br>Return the OCU for repair                                                                                          |
| 10 flashes                | Hardware Fault                                          | Change the transmitter board*<br>Return the OCU for repair                                                                                                                             |

\*Qualified personnel only

If necessary, contact Cattron at [www.cattron.com/contact](http://www.cattron.com/contact) for the replacement part number applicable to your system configuration.



## 6 Maintenance Instructions

Unless customer technicians receive formal maintenance training from Cattron, our maintenance philosophy is that inoperative OCUs be returned as complete units to our workshops for repair. This is to ensure functional safety is maintained.

---

**Note:** When returning an OCU for repair, remove the original TransKey supplied with the unit and retain it for use with your spare unit.

---

### 6.1 Preventive Maintenance

Preventive maintenance is limited to the following:

#### Daily Visual Inspection:

Before use, visually inspect the OCU for cleanliness, physical damage and security of external parts (screws, battery pack, switches, etc.). Cattron emphasizes that regular visual inspections not only mean quickly locating a source of potential problems, but also may prevent serious problems from developing later.

#### Cleaning the Transmitter:

Clean the OCU with a moist cloth, and then wipe dry with a clean paper towel.

|                                                                                    |                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>WARNING</b>                                                                                                                                                                                                                                        |
|                                                                                    | ONLY CLEAN THE OCU EXTERIOR RESIN USING METHYL OR ISOPROPYL ALCOHOL, MILD SOAP SOLUTIONS, HEPTANE OR HEXANE. DO NOT CLEAN WITH PARTIALLY HYDROGENATED HYDROCARBONS, KETONES (SUCH AS MEK), STRONG ACIDS OR WITH ALKALINES (SUCH AS SODIUM HYDROXIDE). |

|                                                                                     |                                  |
|-------------------------------------------------------------------------------------|----------------------------------|
|  | <b>WARNING</b>                   |
|                                                                                     | DO NOT IMMERSE THE OCU IN WATER. |

#### Functional Check:

Perform a functional check by operating the OCU in accordance with the Operating Procedures for the crane or other controlled machine. Ensure all system control functions are fully operational.



## 7 Technical Data

### 7.1 Transmitter (OCU)

|                               |                                                                                                                                                   |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Frequency bands</b>        | Dependant on region:<br>433-434 MHz (Europe)<br>902-927 MHz (North America and other applicable countries)                                        |
| <b>Transfer rate</b>          | 4.8 - 20 kbps                                                                                                                                     |
| <b>Transmission power</b>     | 1-10 mW (within the allowable limits)                                                                                                             |
| <b>Antenna</b>                | Internal                                                                                                                                          |
| <b>System addresses</b>       | 24 Bit                                                                                                                                            |
| <b>Power-saving mode</b>      | Automatic switch-off (configurable 0 – 30 minutes)                                                                                                |
| <b>Power supply</b>           | Ni-MH, 4.8 V, 1600 mAh, quick-swap rechargeable battery pack                                                                                      |
| <b>Operating time</b>         | >12 h @ 100% duty cycle                                                                                                                           |
| <b>Operating elements</b>     | 2 joysticks<br>STOP, START, HORN<br>5 configurable pushbutton switches, each with an associated LED                                               |
| <b>Indication</b>             | 1 STATUS/multi-function LED<br>6 switch status LEDs<br>LCD display (optional)<br>Acoustic signal for status/tilt/low battery and error indication |
| <b>Weight</b>                 | 2.2 lb (1.0 kg) with the battery installed                                                                                                        |
| <b>Dimensions (L x W x H)</b> | 9 x 4.6 x 6 in (229 x 117 x 152 mm)                                                                                                               |
| <b>Housing</b>                | Lexan EXL Polycarbonate Resin, standard colors: grey/red with black railing                                                                       |
| <b>Operating temperature</b>  | -4° to 140° F (-20° to +60° C)                                                                                                                    |
| <b>Protection class</b>       | IP 65                                                                                                                                             |
| <b>Safety</b>                 | EN 13849-1 Performance Level d for all safety related functions<br>EN 60204-1<br>EN 60204-32<br>CE Compliant                                      |

### 7.2 Battery Charger

|                               |                                                                                                    |
|-------------------------------|----------------------------------------------------------------------------------------------------|
| <b>Model</b>                  | Processor-controlled charger for Ni-MH battery packs                                               |
| <b>Dimensions (W x D x H)</b> | 2.4 x 3.5 x 4.7 in (60 x 90 x 120 mm)                                                              |
| <b>Power supply</b>           | Primary: 100 – 240 VAC, 50/60 Hz, 17 VA, 300 mA<br>Secondary: 1.45 – 14.5 VDC, max. 800 mA, 9.6 VA |




## 8 Technical Support

For remote and communication control systems support, parts and repair, or technical support, visit us online at:  
[www.cattron.com/contact](http://www.cattron.com/contact).



## Appendix – RF Channels

The four LEDs indicating the RF Channel in use can be located on the membrane according to the image below:



### 433-434 MHz Frequency Band (Europe)

| Channel # | Center Frequency (MHz) | OCU LED |       |        |        |
|-----------|------------------------|---------|-------|--------|--------|
|           |                        | 1       | 2     | 3      | 4      |
| 1         | 433.0775               |         |       |        | Red    |
| 2         | 433.1025               |         |       |        | Green  |
| 3         | 433.1275               |         |       |        | Yellow |
| 4         | 433.1525               |         | Red   |        |        |
| 5         | 433.1775               |         | Red   |        | Red    |
| 6         | 433.2025               |         | Red   |        | Green  |
| 7         | 433.2275               |         | Red   |        | Yellow |
| 8         | 433.2525               |         |       | Green  |        |
| 9         | 433.2775               |         |       | Green  | Red    |
| 10        | 433.3025               |         |       | Green  | Green  |
| 11        | 433.3275               |         |       | Green  | Yellow |
| 12        | 433.3525               |         |       | Yellow |        |
| 13        | 433.3775               |         |       | Yellow | Red    |
| 14        | 433.4025               |         |       | Yellow | Green  |
| 15        | 433.4275               |         |       | Yellow | Yellow |
| 16        | 433.4525               | Red     |       |        |        |
| 17        | 433.4775               | Red     |       |        | Red    |
| 18        | 433.5025               | Red     |       |        | Green  |
| 19        | 433.5275               | Red     |       |        | Yellow |
| 20        | 433.5525               | Red     | Red   |        |        |
| 21        | 433.5775               | Red     | Red   |        | Red    |
| 22        | 433.6025               | Red     | Red   |        | Green  |
| 23        | 433.6275               | Red     | Red   |        | Yellow |
| 24        | 433.6525               | Red     | Green |        |        |
| 25        | 433.6775               | Red     | Green |        | Red    |



| Channel # | Center Frequency (MHz) | OCU LED |        |        |        |
|-----------|------------------------|---------|--------|--------|--------|
|           |                        | 1       | 2      | 3      | 4      |
| 26        | 433.7025               |         | Red    | Green  | Green  |
| 27        | 433.7275               |         | Red    | Green  | Yellow |
| 28        | 433.7525               |         | Red    | Yellow |        |
| 29        | 433.7775               |         | Red    | Yellow | Red    |
| 30        | 433.8025               |         | Red    | Yellow | Green  |
| 31        | 433.8275               |         | Red    | Yellow | Yellow |
| 32        | 433.8525               |         | Green  |        |        |
| 33        | 433.8775               |         | Green  |        | Red    |
| 34        | 433.9025               |         | Green  |        | Green  |
| 35        | 433.9275               |         | Green  |        | Yellow |
| 36        | 433.9525               |         | Green  | Red    |        |
| 37        | 433.9775               |         | Green  | Red    | Red    |
| 38        | 434.0025               |         | Green  | Red    | Green  |
| 39        | 434.0275               |         | Green  | Red    | Yellow |
| 40        | 434.0525               |         | Green  | Green  |        |
| 41        | 434.0775               |         | Green  | Green  | Red    |
| 42        | 434.1025               |         | Green  | Green  | Green  |
| 43        | 434.1275               |         | Green  | Green  | Yellow |
| 44        | 434.1525               |         | Green  | Yellow |        |
| 45        | 434.1775               |         | Green  | Yellow | Red    |
| 46        | 434.2025               |         | Green  | Yellow | Green  |
| 47        | 434.2275               |         | Green  | Yellow | Yellow |
| 48        | 434.2525               |         | Yellow |        |        |
| 49        | 434.2775               |         | Yellow |        | Red    |
| 50        | 434.3025               |         | Yellow |        | Green  |
| 51        | 434.3275               |         | Yellow |        | Yellow |
| 52        | 434.3525               |         | Yellow | Red    |        |
| 53        | 434.3775               |         | Yellow | Red    | Red    |
| 54        | 434.4025               |         | Yellow | Red    | Green  |
| 55        | 434.4275               |         | Yellow | Red    | Yellow |
| 56        | 434.4525               |         | Yellow | Green  |        |
| 57        | 434.4775               |         | Yellow | Green  | Red    |
| 58        | 434.5025               |         | Yellow | Green  | Green  |
| 59        | 434.5275               |         | Yellow | Green  | Yellow |
| 60        | 434.5525               |         | Yellow | Yellow |        |
| 61        | 434.5775               |         | Yellow | Yellow | Red    |
| 62        | 434.6025               |         | Yellow | Yellow | Green  |
| 63        | 434.6275               |         | Yellow | Yellow | Yellow |



| Channel # | Center Frequency (MHz) | OCU LED |   |   |   |
|-----------|------------------------|---------|---|---|---|
|           |                        | 1       | 2 | 3 | 4 |
| 64        | 434.6525               |         |   |   |   |
| 65        | 434.6775               |         |   |   |   |
| 66        | 434.7025               |         |   |   |   |
| 67        | 434.7275               |         |   |   |   |
| 68        | 434.7525               |         |   |   |   |
| 69        | 434.7775               |         |   |   |   |

## 902-927 MHz Frequency Band (North America and other applicable countries)

Operation mode: OM005, OM011, OM012

| Cluster | Channel # | Freq. (MHz) | OCU LED |   |   |   |
|---------|-----------|-------------|---------|---|---|---|
|         |           |             | 1       | 2 | 3 | 4 |
| 0       | 1         | 903.00      |         |   |   |   |
| 0       | 2         | 904.20      |         |   |   |   |
| 0       | 3         | 905.40      |         |   |   |   |
| 0       | 4         | 906.60      |         |   |   |   |
| 0       | 5         | 907.80      |         |   |   |   |
| 0       | 6         | 909.00      |         |   |   |   |
| 0       | 7         | 918.60      |         |   |   |   |
| 0       | 8         | 919.80      |         |   |   |   |
| 0       | 9         | 921.00      |         |   |   |   |
| 0       | 10        | 922.20      |         |   |   |   |
| 0       | 11        | 923.40      |         |   |   |   |
| 1       | 12        | 903.20      |         |   |   |   |
| 1       | 13        | 904.40      |         |   |   |   |
| 1       | 14        | 905.60      |         |   |   |   |
| 1       | 15        | 906.80      |         |   |   |   |
| 1       | 16        | 908.00      |         |   |   |   |
| 1       | 17        | 909.20      |         |   |   |   |
| 1       | 18        | 918.80      |         |   |   |   |
| 1       | 19        | 920.00      |         |   |   |   |
| 1       | 20        | 921.20      |         |   |   |   |
| 1       | 21        | 922.40      |         |   |   |   |
| 1       | 22        | 923.60      |         |   |   |   |
| 2       | 23        | 903.40      |         |   |   |   |
| 2       | 24        | 904.60      |         |   |   |   |
| 2       | 25        | 905.80      |         |   |   |   |





| Cluster | Channel # | Freq. (MHz) | OCU LED |        |        |        |
|---------|-----------|-------------|---------|--------|--------|--------|
|         |           |             | 1       | 2      | 3      | 4      |
| 2       | 26        | 907.00      |         | Red    | Green  | Green  |
| 2       | 27        | 908.20      |         | Red    | Green  | Yellow |
| 2       | 28        | 909.40      |         | Red    | Yellow |        |
| 2       | 29        | 919.00      |         | Red    | Yellow | Red    |
| 2       | 30        | 920.20      |         | Red    | Yellow | Green  |
| 2       | 31        | 921.40      |         | Red    | Yellow | Yellow |
| 2       | 32        | 922.60      |         | Green  |        |        |
| 2       | 33        | 923.80      |         | Green  |        | Red    |
| 3       | 34        | 903.60      |         | Green  |        | Green  |
| 3       | 35        | 904.80      |         | Green  |        | Yellow |
| 3       | 36        | 906.00      |         | Green  | Red    |        |
| 3       | 37        | 907.20      |         | Green  | Red    | Red    |
| 3       | 38        | 908.40      |         | Green  | Red    | Green  |
| 3       | 39        | 909.60      |         | Green  | Red    | Yellow |
| 3       | 40        | 919.20      |         | Green  | Green  |        |
| 3       | 41        | 920.40      |         | Green  | Green  | Red    |
| 3       | 42        | 921.60      |         | Green  | Green  | Green  |
| 3       | 43        | 922.80      |         | Green  | Green  | Yellow |
| 3       | 44        | 924.00      |         | Green  | Yellow |        |
| 4       | 45        | 903.80      |         | Green  | Yellow | Red    |
| 4       | 46        | 905.00      |         | Green  | Yellow | Green  |
| 4       | 47        | 906.20      |         | Green  | Yellow | Yellow |
| 4       | 48        | 907.40      |         | Yellow |        |        |
| 4       | 49        | 908.60      |         | Yellow |        | Red    |
| 4       | 50        | 919.40      |         | Yellow |        | Green  |
| 4       | 51        | 920.60      |         | Yellow |        | Yellow |
| 4       | 52        | 921.80      |         | Yellow | Red    |        |
| 4       | 53        | 923.00      |         | Yellow | Red    | Red    |
| 4       | 54        | 924.20      |         | Yellow | Red    | Green  |
| 5       | 55        | 904.00      |         | Yellow | Red    | Yellow |
| 5       | 56        | 905.20      |         | Yellow | Green  |        |
| 5       | 57        | 906.40      |         | Yellow | Green  | Red    |
| 5       | 58        | 907.60      |         | Yellow | Green  | Green  |
| 5       | 59        | 908.80      |         | Yellow | Green  | Yellow |
| 5       | 60        | 918.40      |         | Yellow | Yellow |        |
| 5       | 61        | 919.60      |         | Yellow | Yellow | Red    |
| 5       | 62        | 920.80      |         | Yellow | Yellow | Green  |



| Cluster | Channel # | Freq. (MHz) | OCU LED |   |   |   |
|---------|-----------|-------------|---------|---|---|---|
|         |           |             | 1       | 2 | 3 | 4 |
| 5       | 63        | 922.00      |         |   |   |   |
| 5       | 64        | 923.20      |         |   |   |   |
| 5       | 65        | 924.40      |         |   |   |   |

Operation mode: **OM005**, **OM011**

| Cluster | Channel # | Freq. (MHz) | OCU LED |   |   |   |
|---------|-----------|-------------|---------|---|---|---|
|         |           |             | 1       | 2 | 3 | 4 |
| 6       | 66        | 902.60      |         |   |   |   |
| 6       | 67        | 910.60      |         |   |   |   |
| 6       | 68        | 911.80      |         |   |   |   |
| 6       | 69        | 913.00      |         |   |   |   |
| 6       | 70        | 914.20      |         |   |   |   |
| 6       | 71        | 915.40      |         |   |   |   |
| 6       | 72        | 916.60      |         |   |   |   |
| 6       | 73        | 917.80      |         |   |   |   |
| 6       | 74        | 925.20      |         |   |   |   |
| 6       | 75        | 926.40      |         |   |   |   |
| 7       | 76        | 902.80      |         |   |   |   |
| 7       | 77        | 910.80      |         |   |   |   |
| 7       | 78        | 912.00      |         |   |   |   |
| 7       | 79        | 913.20      |         |   |   |   |
| 7       | 80        | 914.40      |         |   |   |   |
| 7       | 81        | 915.60      |         |   |   |   |
| 7       | 82        | 916.80      |         |   |   |   |
| 7       | 83        | 918.00      |         |   |   |   |
| 7       | 84        | 925.40      |         |   |   |   |
| 7       | 85        | 926.60      |         |   |   |   |
| 8       | 86        | 909.80      |         |   |   |   |
| 8       | 87        | 911.00      |         |   |   |   |
| 8       | 88        | 912.20      |         |   |   |   |
| 8       | 89        | 913.40      |         |   |   |   |
| 8       | 90        | 914.60      |         |   |   |   |
| 8       | 91        | 915.80      |         |   |   |   |
| 8       | 92        | 917.00      |         |   |   |   |
| 8       | 93        | 918.20      |         |   |   |   |
| 8       | 94        | 925.60      |         |   |   |   |
| 8       | 95        | 926.80      |         |   |   |   |



| Cluster | Channel # | Freq. (MHz) | OCU LED |        |        |        |
|---------|-----------|-------------|---------|--------|--------|--------|
|         |           |             | 1       | 2      | 3      | 4      |
| 9       | 96        | 910.00      | Red     | Green  |        |        |
| 9       | 97        | 911.20      | Red     | Green  |        | Red    |
| 9       | 98        | 912.40      | Red     | Green  |        | Green  |
| 9       | 99        | 913.60      | Red     | Green  |        | Yellow |
| 9       | 100       | 914.80      | Red     | Green  | Red    |        |
| 9       | 101       | 916.00      | Red     | Green  | Red    | Red    |
| 9       | 102       | 917.20      | Red     | Green  | Red    | Green  |
| 9       | 103       | 924.60      | Red     | Green  | Red    | Yellow |
| 9       | 104       | 925.80      | Red     | Green  | Green  |        |
| 9       | 105       | 927.00      | Red     | Green  | Green  | Red    |
| 10      | 106       | 910.20      | Red     | Green  | Green  | Green  |
| 10      | 107       | 911.40      | Red     | Green  | Green  | Yellow |
| 10      | 108       | 912.60      | Red     | Green  | Yellow |        |
| 10      | 109       | 913.80      | Red     | Green  | Yellow | Red    |
| 10      | 110       | 915.00      | Red     | Green  | Yellow | Green  |
| 10      | 111       | 916.20      | Red     | Green  | Yellow | Yellow |
| 10      | 112       | 917.40      | Red     | Yellow |        |        |
| 10      | 113       | 924.80      | Red     | Yellow |        | Red    |
| 10      | 114       | 926.00      | Red     | Yellow |        | Green  |
| 10      | 115       | 927.20      | Red     | Yellow |        | Yellow |
| 11      | 116       | 910.40      | Red     | Yellow | Red    |        |
| 11      | 117       | 911.60      | Red     | Yellow | Red    | Red    |
| 11      | 118       | 912.80      | Red     | Yellow | Red    | Green  |
| 11      | 119       | 914.00      | Red     | Yellow | Red    | Yellow |
| 11      | 120       | 915.20      | Red     | Yellow | Green  |        |
| 11      | 121       | 916.40      | Red     | Yellow | Green  | Red    |
| 11      | 122       | 917.60      | Red     | Yellow | Green  | Green  |
| 11      | 123       | 925.00      | Red     | Yellow | Green  | Yellow |
| 11      | 124       | 926.20      | Red     | Yellow | Yellow |        |
| 11      | 125       | 927.40      | Red     | Yellow | Yellow | Red    |

**Operation Mode: OM012**

| Cluster | Channel # | Freq. (MHz) | OCU LED |        |        |        |
|---------|-----------|-------------|---------|--------|--------|--------|
|         |           |             | 1       | 2      | 3      | 4      |
| 12      | 126       | 903.10      | Red     | Yellow | Yellow | Green  |
| 12      | 127       | 904.30      | Red     | Yellow | Yellow | Yellow |
| 12      | 128       | 905.50      | Green   |        |        |        |



| Cluster | Channel # | Freq. (MHz) | OCU LED |   |   |   |
|---------|-----------|-------------|---------|---|---|---|
|         |           |             | 1       | 2 | 3 | 4 |
| 12      | 129       | 906.70      |         |   |   |   |
| 12      | 130       | 907.90      |         |   |   |   |
| 12      | 131       | 909.10      |         |   |   |   |
| 12      | 132       | 918.70      |         |   |   |   |
| 12      | 133       | 919.90      |         |   |   |   |
| 12      | 134       | 921.10      |         |   |   |   |
| 12      | 135       | 922.30      |         |   |   |   |
| 12      | 136       | 923.50      |         |   |   |   |
| 13      | 137       | 903.30      |         |   |   |   |
| 13      | 138       | 904.50      |         |   |   |   |
| 13      | 139       | 905.70      |         |   |   |   |
| 13      | 140       | 906.90      |         |   |   |   |
| 13      | 141       | 908.10      |         |   |   |   |
| 13      | 142       | 909.30      |         |   |   |   |
| 13      | 143       | 918.90      |         |   |   |   |
| 13      | 144       | 920.10      |         |   |   |   |
| 13      | 145       | 921.30      |         |   |   |   |
| 13      | 146       | 922.50      |         |   |   |   |
| 13      | 147       | 923.70      |         |   |   |   |
| 14      | 148       | 903.50      |         |   |   |   |
| 14      | 149       | 904.70      |         |   |   |   |
| 14      | 150       | 905.90      |         |   |   |   |
| 14      | 151       | 907.10      |         |   |   |   |
| 14      | 152       | 908.30      |         |   |   |   |
| 14      | 153       | 909.50      |         |   |   |   |
| 14      | 154       | 919.10      |         |   |   |   |
| 14      | 155       | 920.30      |         |   |   |   |
| 14      | 156       | 921.50      |         |   |   |   |
| 14      | 157       | 922.70      |         |   |   |   |
| 14      | 158       | 923.90      |         |   |   |   |
| 15      | 159       | 903.70      |         |   |   |   |
| 15      | 160       | 904.90      |         |   |   |   |
| 15      | 161       | 906.10      |         |   |   |   |
| 15      | 162       | 907.30      |         |   |   |   |
| 15      | 163       | 908.50      |         |   |   |   |
| 15      | 164       | 909.70      |         |   |   |   |
| 15      | 165       | 919.30      |         |   |   |   |



| Cluster | Channel # | Freq. (MHz) | OCU LED |   |   |   |
|---------|-----------|-------------|---------|---|---|---|
|         |           |             | 1       | 2 | 3 | 4 |
| 15      | 166       | 920.50      |         |   |   |   |
| 15      | 167       | 921.70      |         |   |   |   |
| 15      | 168       | 922.90      |         |   |   |   |
| 15      | 169       | 924.10      |         |   |   |   |
| 16      | 170       | 903.90      |         |   |   |   |
| 16      | 171       | 905.10      |         |   |   |   |
| 16      | 172       | 906.30      |         |   |   |   |
| 16      | 173       | 907.50      |         |   |   |   |
| 16      | 174       | 908.70      |         |   |   |   |
| 16      | 175       | 919.50      |         |   |   |   |
| 16      | 176       | 920.70      |         |   |   |   |
| 16      | 177       | 921.90      |         |   |   |   |
| 16      | 178       | 923.10      |         |   |   |   |
| 16      | 179       | 924.30      |         |   |   |   |
| 17      | 180       | 904.10      |         |   |   |   |
| 17      | 181       | 905.30      |         |   |   |   |
| 17      | 182       | 906.50      |         |   |   |   |
| 17      | 183       | 907.70      |         |   |   |   |
| 17      | 184       | 908.90      |         |   |   |   |
| 17      | 185       | 918.50      |         |   |   |   |
| 17      | 186       | 919.70      |         |   |   |   |
| 17      | 187       | 920.90      |         |   |   |   |
| 17      | 188       | 922.10      |         |   |   |   |
| 17      | 189       | 923.30      |         |   |   |   |
| 17      | 190       | 924.50      |         |   |   |   |
| 18      | 191       | 902.70      |         |   |   |   |
| 18      | 192       | 910.70      |         |   |   |   |
| 18      | 193       | 911.90      |         |   |   |   |
| 18      | 194       | 913.10      |         |   |   |   |
| 18      | 195       | 914.30      |         |   |   |   |
| 18      | 196       | 915.50      |         |   |   |   |
| 18      | 197       | 916.70      |         |   |   |   |
| 18      | 198       | 917.90      |         |   |   |   |
| 18      | 199       | 925.30      |         |   |   |   |
| 18      | 200       | 926.50      |         |   |   |   |
| 19      | 201       | 902.90      |         |   |   |   |
| 19      | 202       | 910.90      |         |   |   |   |



| Cluster | Channel # | Freq. (MHz) | OCU LED |   |   |   |
|---------|-----------|-------------|---------|---|---|---|
|         |           |             | 1       | 2 | 3 | 4 |
| 19      | 203       | 912.10      |         |   |   |   |
| 19      | 204       | 913.30      |         |   |   |   |
| 19      | 205       | 914.50      |         |   |   |   |
| 19      | 206       | 915.70      |         |   |   |   |
| 19      | 207       | 916.90      |         |   |   |   |
| 19      | 208       | 918.10      |         |   |   |   |
| 19      | 209       | 925.50      |         |   |   |   |
| 19      | 210       | 926.70      |         |   |   |   |
| 20      | 211       | 909.90      |         |   |   |   |
| 20      | 212       | 911.10      |         |   |   |   |
| 20      | 213       | 912.30      |         |   |   |   |
| 20      | 214       | 913.50      |         |   |   |   |
| 20      | 215       | 914.70      |         |   |   |   |
| 20      | 216       | 915.90      |         |   |   |   |
| 20      | 217       | 917.10      |         |   |   |   |
| 20      | 218       | 918.30      |         |   |   |   |
| 20      | 219       | 925.70      |         |   |   |   |
| 20      | 220       | 926.90      |         |   |   |   |
| 21      | 221       | 910.10      |         |   |   |   |
| 21      | 222       | 911.30      |         |   |   |   |
| 21      | 223       | 912.50      |         |   |   |   |
| 21      | 224       | 913.70      |         |   |   |   |
| 21      | 225       | 914.90      |         |   |   |   |
| 21      | 226       | 916.10      |         |   |   |   |
| 21      | 227       | 917.30      |         |   |   |   |
| 21      | 228       | 924.70      |         |   |   |   |
| 21      | 229       | 925.90      |         |   |   |   |
| 21      | 230       | 927.10      |         |   |   |   |
| 22      | 231       | 910.30      |         |   |   |   |
| 22      | 232       | 911.50      |         |   |   |   |
| 22      | 233       | 912.70      |         |   |   |   |
| 22      | 234       | 913.90      |         |   |   |   |
| 22      | 235       | 915.10      |         |   |   |   |
| 22      | 236       | 916.30      |         |   |   |   |
| 22      | 237       | 917.50      |         |   |   |   |
| 22      | 238       | 924.90      |         |   |   |   |
| 22      | 239       | 926.10      |         |   |   |   |



| Cluster | Channel # | Freq. (MHz) | OCU LED |        |       |        |
|---------|-----------|-------------|---------|--------|-------|--------|
|         |           |             | 1       | 2      | 3     | 4      |
| 22      | 240       | 927.30      | Yellow  | Yellow |       |        |
| 23      | 241       | 910.50      | Yellow  | Yellow |       | Red    |
| 23      | 242       | 911.70      | Yellow  | Yellow |       | Green  |
| 23      | 243       | 912.90      | Yellow  | Yellow |       | Yellow |
| 23      | 244       | 914.10      | Yellow  | Yellow | Red   |        |
| 23      | 245       | 915.30      | Yellow  | Yellow | Red   | Red    |
| 23      | 246       | 916.50      | Yellow  | Yellow | Red   | Green  |
| 23      | 247       | 917.70      | Yellow  | Yellow | Red   | Yellow |
| 23      | 248       | 925.10      | Yellow  | Yellow | Green |        |
| 23      | 249       | 926.30      | Yellow  | Yellow | Green | Red    |
| 23      | 250       | 927.50      | Yellow  | Yellow | Green | Green  |



Due to continuous product improvement, the information provided in this document is subject to change without notice.

**Cattron Wireless Automation and Control Solutions Support**

For remote and communication control systems support, parts and repair, or technical support, visit us online at:  
[www.cattron.com/contact](http://www.cattron.com/contact)

Cattron North America Inc., 655 N River Rd NW, Suite A, Warren, OH 44483